

To Connect a C1 Speaker to a P1 subwoofer for use as a powered center channel, or for any channel of the system.

The C1 speaker does not dock to the SCT™ rails like the other bookshelf models, but these two speakers **ARE** designed to integrate, and there is a C1 crossover mode setting on the P1 subwoofer.

- 1) Using standard 2 conductor high quality speaker cable, connect a cable from the center speaker output (or whatever channel you are using this speaker combination for) of the Receiver or Amplifier, to the Binding Post Connectors on the **P1 subwoofer**, marked "**C1/S1/S2/S3/IN**" ensuring the positive (red) and negative (black) connectors are matched.
- 2) Next, connect another cable from the Binding Post Connectors on the **subwoofer**, marked "**Left Spkr Out**" and connect it to the Binding Post Connectors on the C1 speaker.
- 3) Proceed to the next chapter to ensure the Mode switch is set correctly.

